

Colour Sample Table

In addition to the classic black and white colours, digital pianos, pianos and grand pianos are also available in many other colour tones. Andexinger has been manufacturing special chairs and benches for these instruments in many different designs for the last few decades. From modern and rustic to nostalgic, everything is catered for.

This overview helps you find the right colour tones and fabric/ leather covers for the piano bench you have selected in the Thomann Store. You can then leave a comment on your order, specifying the exact wood colour tone of your preference. Please note, that custom orders are excluded from our 30-Day Money-Back Guarantee.

The standard colours shown below provide a guideline and are included in the price of each model. All stained wood colours are also available as polished versions for an additional charge. Covers made of genuine leather or more expensive materials will incur a surcharge made by Andexinger. Of course, Andexinger can also provide you with a bench or chair in a colour tone of your choice, by sending in your own sample. The same applies for the cushion covers as well.

Please note that the samples below should be treated as a representation and that the original may vary.

Andexinger

th•mann
MUSIC IS OUR PASSION

Wood- colour tones

P 10 - Walnut,
medium, brown



P 11
Walnut, dark



P 37
Mahogany, medium



P33 - Mahogany,
Rosewood dark



White, matt
or polished



Black, matt
or polished



Beech



Oak, natural



Alder



P 30
Cherry, Elm




Cherry, medium



P 21
Walnut, light brown








P 31
Walnut, medium,
Red-brown









Covers for piano chairs and benches

Genuine Leather – extra charge applicable




Artificial Leather – included in price




Covers for piano chairs and benches

Plush Uni Fabric – extra charge applicable


20A



21A




22A




23A



24A




25A




Plush with pattern – extra charge applicable

26A




27A




28A



29A



30A




31A




Covers for piano chairs and benches

Fabrics – included in price

40A




41A




42A



44A




45A




46A




47A



48A




49A



51A



53A












54A



Covers for piano chairs and benches

Fabrics – extra charge applicable



Individual Fabrics – extra charge applicable

You can also send us your own cushion fabric which we would incur an additional charge.