



Millenium

BS-2211B MKII Set
speaker stand

Musikhaus Thomann
Thomann GmbH
Hans-Thomann-Straße 1
96138 Burgebrach
Germany
Telephone: +49 (0) 9546 9223-0
E-mail: info@thomann.de
Internet: www.thomann.de

04.11.2019, ID: 304849

Table of contents

1	General information.....	4
2	Safety notes.....	6
3	Features.....	9
4	Operating.....	10
5	Technical specifications.....	15
6	Protecting the environment.....	17

1 General information

This manual contains important instructions for the safe operation of the product. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the product. If you sell the product to another user, be sure that they also receive this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change. Please refer to the latest version of the user manual which is ready for download under www.thomann.de.

Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – danger zone.

2 Safety notes

Intended use

This speaker stand is used for stable fixing and height-adjustable installation of loudspeaker cabinets. Use the product only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This product may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this product only if they are supervised or instructed by a person who is responsible for their safety.

Safety**DANGER!****Danger for children**

Ensure that plastic bags, packaging, etc. are properly disposed of and are not in the reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the product. They could swallow the pieces and choke!

Never let children play unattended with the product.

**CAUTION!****Danger of tipping when transported under load**

If the stand is moved without having removed the installed device, the stand may tip over and cause injuries and property damage.

Remove the installed device before transporting the stand.



CAUTION!

Danger of tipping on unsuitable surfaces

When the speaker stand is installed on soft or uneven ground, the stand may tip over and cause injuries and property damage.

Install the stand only on even and solid surfaces.



CAUTION!

Danger of tipping due to overload

In case of overload, the stand may tip over and cause injuries and property damage.

Never exceed the maximum load capacity specified for the stand.

3 Features

Special features:

- 2 pcs. set including carrying bag
- Elegant all metal construction
- Extendable up to 2 m
- Up to 30 kg centrally loadable
- 35 mm pipe diameter at the tripod flange
- Transport length when folded: 1.12 m

4 Operating

Unpack and check carefully there is no transportation damage before using the product. Keep the equipment packaging. To fully protect the product against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.



CAUTION!

Danger of tipping when transported under load

If the stand is moved without having removed the installed device, the stand may tip over and cause injuries and property damage.

Remove the installed device before transporting the stand.



CAUTION!

Danger of tipping on unsuitable surfaces

When the speaker stand is installed on soft or uneven ground, the stand may tip over and cause injuries and property damage.

Install the stand only on even and solid surfaces.



CAUTION!

Danger of tipping due to overload

In case of overload, the stand may tip over and cause injuries and property damage.

Never exceed the maximum load capacity specified for the stand.



NOTICE!

Possible staining

The plasticiser contained in the rubber feet of this product may possibly react with the coating of your parquet, linoleum, laminate or PVC floor and after some time cause permanent dark stains.

In case of doubt, do not put the rubber feet directly on the floor, but use felt-pad floor protectors or a carpet.



Comply with regulations

When installing and operating, make sure to follow the standards and regulations that apply in your country.

Setting up



Follow the procedure described below for each of both stands:

1. ➤ Unfold the feet of the stand until the cross braces are in a horizontal position.
2. ➤ Fix this position with the safety screw on the slider to which the three feet are attached.
3. ➤ Pull out the safety cotter and loosen the locking screw on the extension tube.
4. ➤ Pull out the extension tube to the desired height and slide the safety cotter through the corresponding grid hole.
5. ➤ Fix the position of the extension tube with the safety bolt on the extension tube.
6. ➤ Flange the speaker box on top of the extension tube. The weight of the speaker box to be set up must not exceed the maximum centric load of 30 kg.

Dismounting

1. ▶ Remove the speaker box.
2. ▶ Pull out the safety cotter and hold the extension tube while you loosen the locking screw on the extension tube.
3. ▶ Slide the extension tube all the way down and slide the safety cotter through the corresponding grid hole.
4. ▶ Fix the position of the extension tube with the safety bolt on the extension tube.
5. ▶ Loosen the safety screw on the slider to which the three feet are attached.
6. ▶ Fold up the feet of the stand.

5 Technical specifications

Height, max.	2 × 2.00 m
Adjustable stand height	2 × 1.25 m ... 2.00 m
Stand footprint	2 × Ø 775 mm
Truss length	2 × 1042 mm
Stand tube diameter	Ø 35 mm
Truss tube diameter	Ø 38 mm
Mounting options	Flange, 2 × Ø 35 mm
Max. load capacity (for centric load)	2 × 30 kg
Transport dimensions (W × H × D)	250 mm × 1150 mm × 120 mm
Weight	2 × 2.16 kg
Colour	Black

Further information

Set of 2 stands	Yes
Speaker flange	35 mm
Material	Aluminium
Crank stand	No
Ringlock	No
Pneumatics	No
Foot type	Tripod

6 Protecting the environment

Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



