



- ✓ Chromatic tuner
- ✓ Allows superfast tuning
- ✓ Bright colour LCD
- ✓ Display rotatable by 360°
- ✓ Available tune modes:  
Chromatic/guitar/bass/violin/ukulele/ukulele-D
- ✓ Sensitive Piezo sensor
- ✓ Automatic energy saver mode
- ✓ Includes 3 V lithium battery (CR2032)
- ✓ Finish (matt rubberised):  
Red (318364) or black (493736)

## Safety instructions

- ▶ Ensure that plastic bags, packaging, etc. are properly disposed of and are not in the reach of babies and young children. Choking hazard!
- ▶ Do not operate or store the unit in locations, where it is exposed to heat, precipitation, high humidity, pollution, or strong vibrations. Indoor use only!
- ▶ Never try to dismantle or repair the unit by yourself in case it doesn't work.
- ▶ Never operate the device with a supply voltage other than that stated here. Otherwise the unit will be damaged.
- ▶ Never use solvents like alcohol etc. for cleaning the unit.



## Protecting the environment

- ▶ This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility. Batteries must not be disposed of as domestic waste or thrown into fire.
- ▶ Dispose of the batteries according to national or local regulations regarding hazardous waste.



Calibration: 440 - 449 Hz

Dimensions (L x B x H): 53 x 43 x 4 mm

Weight: 29 g